

Installation instructions Toyota Hilux Vigo (2005-2015)

- without installation points – mostly common in Scandinavia and South Africa

please see attached videos showing access to the inner cavity on our Vigo.

If the lack of mounting bracket points is the only difference between the Swedish Vigo and the South African Vigo then they could do the following:

1. Dry fit the canopy camper to the customers vehicle.
2. Align the mounting brackets with the canopy / canopy camper frame and mark the position of the mounting holes on the brackets on the load bin.
3. Remove the rear wheel arch protection cover on both sides along with the taillights.
4. Carefully drill the holes out on the load-bin, ensuring you only drill into the space between the outer skin and the inner skin.
5. Make a backing plate (from flat bar or similar material) for the inside cavity that matches the hole positions on the mounting brackets.
6. Seal the backing plate and the drilled holes to prevent rust and corrosion.
7. Hold the backing plate in position, line the holes up in the load bin, the mounting bracket and the backing plate and guide the supplied bolts through. Use a nylock nut to secure the bolts in position.
8. Once the mounting brackets have been fastened down refit the wheel arch covers and taillights and complete the installation.

An important note: The custom mounting points on the load-bin are not load rated, therefore we cannot guarantee that should you opt to mount the canopy or canopy camper in this way that there will be no damage to the customers vehicle during use. The above installation guide's purpose is just advice on how to fit the canopies or canopy campers and we cannot guarantee that the solution will be structurally sound.